

# Steering units/steering pump



## Selection


### Load sensing function pipe mounting



**101-5T\*\***  
(Danfoss OSPB LS)  
(M+S HKU\*/5T )  
**101S-5T\*\***  
(Danfoss OSPC\* LS)  
(M+S HKUS\*/5T\*)



### Load sensing function modular mounting



**101S-5T\*\***  
(Danfoss OSPC\* LS)  
(M+S HKUS\*/5\*)



### Without valve function



**101-1**  
(Danfoss OSPB ON)  
(M+S HKU\*/4)



**101-2**  
(M+S HKU\*/3)



**101-3**  
(Danfoss OSPB CN)  
(M+S HKU\*/7)



**101S-1**  
(Danfoss OSPC ON)  
(M+S HKUS\*/4)



**101S-2**  
(Danfoss OSPC OR)  
(M+S HKUS\*/3)



**101S-4**  
(M+S HKUS\*/8)

### Big displacement SCU



### Steering column



For more model details please contact with sales@hpm.cc, For example Danfoss OSPB\*\* OR, OSPB \*\*\* ON, OSPB \*\*\* CN, OSPC \*\*\* ON, OSPC \*\*\* OR, OSPC \*\*\* LS (OLSA), OSPC \*\*\* LS, (OLS), OSPB \*\*\* LS, OSPL \*\*\* LS, OLSA 40,80, OLS 40,80, OLS 160, OVP 10, OVP 15, OVP 20, OVPK 10, OVPK 15, OVPK 20, OVPKO 24, OVPR, OVR 10, OVR 15, OVR 20.

M+S

HKU#/4, HKU#/3, HKU#/7, HKUS#/4-\* , HKUS#/3-\* , HKUS#/8-\* , HKU\*/5T, HKUS#/5-\* , HKUS#/5E-\* , HKUS#/5T-\* , HKUS#/5TE-\* , PRD-40,80 etc.